

Lux Wallcoverings

Standard Installation Guide for Vinyl Wallcoverings

Features of Vinyl Wallcoverings

- Standard open time : 15-20 min
- Cover the wallpaper with protective material like plastic bags to avoid too much drying when taking soaking time more than an hour.

Preparation Tips

- Please be careful not to take too much soaking time in dry season.
- Apply adhesive evenly. Suitable amount of adhesive is approx. 150 g/sqm.

Installation

- Insufficient soaking time will result in expansion after wallcoverings is installed on the wall which may cause bubbles.
- Too much soaking time will result in over drying and the backing paper can be peeled off.
- Too much adhesive will wet the surface of the wallcoverings. This wet surface will slow the drying of the adhesive, and will lead to opening of the seams after installation.
- Low-temperature can be causing peeling since it makes the wallpaper stiff and decline in adhesion.

Subwall and Job Site Condition

- The subwall must be even, firm, crack free, dry, clean and free from remainings of former coverings and adhesives.
- The job site condition such as temperature or humidity should be suitable for the product and the adhesive used.
- Keep the job site warm as all adhesives for wallcovering are water-based.
- Low-temperature may decline in adhesive performance. It also could make the wallpaper curled and harder to install.

Adhesive

- Make optimum adhesive with mixing BB 378 and BB 308 .
- Use BB 307 without dilution.

After installation

- Air the room and allow fresh air to flow through the job site and to ensure the wallpaper dries properly after installation. However, avoid direct sunlight and a sudden temperature change by air conditioner.